

# Shoreline Erosion Control Techniques 101 Part 1

2011 Wisconsin Lake Convention

Carolyn Scholl, Vilas County Conservationist

# Talking Points

## Terminology

## Erosion Concepts

Shoreland Zones

Erosion Factors – Active / Passive

## Planning Concepts

Site Evaluation

WDNR Links – Permits

Assistance

# Terminology

ASNRI Waters

NRCS

Topographic Survey

Bank Height

OHWM

WDNR

Biological Method

PNW

Wind / Wave

DATCP

Public Rights Feature

Energy Category

Riprap

Erosion

Runoff

Erosion Intensity

Seeps

Fetch Calculation

Slope

Geotextile

Storm Wave Height


Impervious

Structural Method


LWCD

Toe Erosion

# Erosion Concepts – Shoreland Zones



# Erosion Concepts – Shoreland Zones



# Erosion Factors – Active / Passive

## ACTIVE

- Rainsplash & Runoff
- Waves – wind / boat driven
- Currents
- Ground Water (seeps)
- Frost thaw / ice impact
- Livestock or human disturbance (ie removal of vegetation)

# Erosion Factors – Active / Passive

## PASSIVE

- Bank or Shoreline Characteristics
  - engineering properties
  - geology
  - geometry
  - vegetative cover
- Adjacent Features/Character
  - land use/development
  - watershed patterns
  - long shore currents
  - tributary areas / flowing water

# Upland Runoff Erosion Factor


10/6/00



Livestock trampling  
of streambank



# Ice Action




Slump in Bank  
due to over-saturation






Human Factor

Unstable Soils  
on a steep bank





Water Level Fluctuations;  
Seawall Overtopping; &  
Splash Impacts



# Planning Concepts – Site Evaluation

Define the cause(s) of erosion:

- Upland runoff? Impervious areas? Velocities?
- Wave energies? Boat or wind generated?
- Ice action? Prevailing wind direction?
- Water level fluctuations? Floods or Droughts?
- Groundwater seeps?
- Up gradient slope and bank height?
- Stability of native soils? Fill soils?

# Planning Concepts – Site Evaluation

## Vegetative Treatment Potential:

- Minimal fetch distance (<0.5 - 1 mile)
- Protected cove or bay (not point or island)
- Shoreline is facing such that prevailing winds do not reach it frequently (i.e. faces east and rarely gets a westerly wind)
- When boat traffic waves are not common or constant (i.e. no motorized traffic allowed, no public landing, SLOW NO WAKE zone = increase the wave intensity)
- When water level fluctuations do not harm vegetation survival rates and/or success

# Planning Concepts – Site Evaluation

## Other Considerations:

- Soil type - conducive to slope stability at given angle without toe protection?
- Parcel development is limiting a stable slope (i.e. home too close to slope break or existing vertical walls)
- Lake channel (narrow areas) or controlled wake areas create constant waves so vegetation can not establish
- Extreme ice action continuously removes or stresses soil/plants
- Erosion intensities are too high for existing vegetation

# Technical Planning Assistance

County Land & Water Conservation Departments

Natural Resource Conservation Service

Wisconsin Department of Natural Resources

Department of Ag, Trade, & Consumer Protection

Private Consultants & Businesses

# Planning Concepts – WDNR Web Links

[http://dnr.wi.gov/waterways/factsheets/Erosion\\_Intensity\\_Worksheet.pdf](http://dnr.wi.gov/waterways/factsheets/Erosion_Intensity_Worksheet.pdf)

[http://dnr.wi.gov/waterways/shoreline\\_habitat/erosioncalculator.html](http://dnr.wi.gov/waterways/shoreline_habitat/erosioncalculator.html)

<http://dnrmaps.wisconsin.gov/imf/imf.jsp?site=SurfaceWaterViewer>